

Таблица значений настройки ручных балансировочных клапанов MSV-I.

этаж \ стояк	См1		См2		См3		См4		См5		См6		См7		См8		См9		См10		См11		См12		См13		См14	
	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п	ГВ	п
12 эт.	20	0.55	22	0.25	24	0.55	26	0.75	28	0.35	30	0.6	32	0.5	33	0.8	35	0.25	37	0.55	38	0.8	39	0.3	41	0.35	43	0.8
	21	0.3	23	0.3	25	0.3	27	0.35	29	0.25	31	0.3			34	0.3	36	0.25					40	0.25	42	3.2		
11 эт.	20	0.35	22	0.25	24	0.35	26	0.45	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.55	39	0.35	41	0.25	43	0.5
	21	0.25	23	0.25	25	0.25	27	0.3	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.9		
10 эт.	20	0.35	22	0.25	24	0.35	26	0.45	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.55	39	0.35	41	0.25	43	0.5
	21	0.25	23	0.25	25	0.25	27	0.3	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.8		
9 эт.	20	0.35	22	0.25	24	0.35	26	0.45	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.25	43	0.5
	21	0.25	23	0.25	25	0.25	27	0.3	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.8		
8 эт.	20	0.35	22	0.25	24	0.35	26	0.45	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.25	43	0.5
	21	0.25	23	0.25	25	0.25	27	0.3	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.8		
7 эт.	20	0.35	22	0.25	24	0.35	26	0.45	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.25	43	0.5
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.8		
6 эт.	20	0.35	22	0.25	24	0.35	26	0.4	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.2	43	0.5
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.8		
5 эт.	20	0.35	22	0.25	24	0.35	26	0.4	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.2	43	0.5
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.3	31	0.35			34	0.2	36	0.3					40	0.2	42	0.75		
4 эт.	20	0.35	22	0.25	24	0.35	26	0.4	28	0.25	30	0.4	32	0.35	33	0.5	35	0.2	37	0.4	38	0.5	39	0.35	41	0.2	43	0.45
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.3	31	0.3			34	0.2	36	0.3					40	0.2	42	0.75		
3 эт.	20	0.35	22	0.25	24	0.35	26	0.4	28	0.25	30	0.35	32	0.35	33	0.45	35	0.2	37	0.4	38	0.5	39	0.35	41	0.2	43	0.45
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.3	31	0.3			34	0.2	36	0.25					40	0.2	42	0.65		
2 эт.	20	0.35	22	0.25	24	0.35	26	0.4	28	0.25	30	0.35	32	0.35	33	0.45	35	0.2	37	0.4	38	0.5	39	0.35	41	0.2	43	0.45
	21	0.25	23	0.35	25	0.25	27	0.25	29	0.25	31	0.3			34	0.2	36	0.25					40	0.2	42	0.65		